

ACC-150 Shoulder bag making tutorial

Here is the tutorial of how to make an original shoulder bag

The finished measurement is about: 13" x 10.6" x 3.5" (33cm x 27cm x 9cm).

You can have the hardware kit here:

Zipper and stops, No.5 39cm, No.3,22cm:

<https://www.leathercraftpattern.com/Leather-supplies/zipper>

25mm or 26mm D-ring x2:

<https://www.leathercraftpattern.com/Leather-supplies/ring/Solid-brass-D-ring>

25mm or 26mm dog hook x2:

<https://www.leathercraftpattern.com/Leather-supplies/Hooks/Solid-brass-dog-hook>

25mm needle buckle x1:

<https://www.leathercraftpattern.com/Leather-supplies/Strap-buckle/cart-buckle-Y2020-20mm>

9mm rivet x15:

<https://www.leathercraftpattern.com/Leather-supplies/rivet/red-copper-rivet>

THK snap 12.5mm x1:

<https://www.leathercraftpattern.com/Leather-supplies/snaps/THK-brass-spring-snaps-12.5mm>

Binder and wrapper leather x4:

Cord x3:

<https://www.leathercraftpattern.com/Leather-supplies/Stiffener/long-handle-core-cord>


Material:

Leather: 2.0mm leather about 12 sq.ft

Tutorial

Step 1: Cut flap from off and draw stitching line.





Step 2: Thin edge and wrap A05 on, A05 is longer than real need.



Step 3: Glue A12 on.





Step 4: Punch chisel holes from pattern to leather.



Step 5: Sew orange stitching line only.



Step 6: Cut other pieces from pattern, and punch chisel holes.





Step 7: Polish edge as your need.



Step 8: Find orienting line of A10.



Step 9: Sew A10 on between A03 and A04.





Step 10: Prepare handles, polish edge.



Step 11: Sew A02 on A01 by align with orienting line, only sew green stitching line.



Step 12: Sew 2 pieces of A09 on.




Step 13: Install one piece of handle on.



Step 14: Sew No.3 zipper on zipper hole of A13.



Step 14: Prepare one piece of A06 and its cord.



Step 15: Use sand paper to rough the cord if you need.



Step 16: Glue cord in A06.



Step 17: Fold and shape by bone creaser. Punch chisel holes.



Step 18: Glue A06 along A13 edge. A06 is longer than real need. Use needle as fix tool will make your work easier. But now we have more professional tool, you can have here:

<https://www.leathercraftpattern.com/LCP-High-end-hardware/Leather-locked-pin>





Step 19: Glue A12 on.



Step 20: Sew A14 and A15 together as a ring.



Step 21: Sew them together.



Step 22: Sew front pocket on A04.





Step 23: Make another A06.





Step 24: Thin edge, glue it on and cut redundant part.





www

Step 25: Make zipper, install stops, and sew it on A07.





Step 26: Sew A07 with A08 as ring.



Step 27: Install A11 with D-rings.



Step 28: Install the other piece of handle on.



Step 29: Assemble them together.





Step 30: Converse the gusset.



Step 31: Sew A07 back piece on.



Step 32: Converse grain side outside from zipper opening, the bag is done.

