



Sunglasses Case

Print out your template.

Ensure you print it out at 100% scale.

Cut out the two pieces and tape them together on the flat edge.

Tape it down to your leather with masking tape.

Cut out design and use the guide mark where the holes for hardware and the nose piece will go.

Bevel/sand/burnish the top of the pocket.

Install the hardware. For the nosepiece, I just do a simple X stitch.

Fold up the pocket and mark where the top of it will sit on both sides with your awl.

Glue both sides and allow 10-15 minutes for it to set.

Do a quick sanding to ensure a nice smooth edge.

Mark your stitching line with your wing dividers.

Mark and punch your stitching holes.

Saddle stitch both sides.

Bevel/sand/burnish all remaining edges.

Apply your leather finish of choice.

When printing, make sure to print the true size. Measure below to ensure the image hasn't been scaled:





