


SCALE TEST

IMPORTANT!
Please make sure that print scale is set to 100% and "auto-scaling" is turned off prior to printing.



SCALE TEST

IMPORTANT!
Please make sure that print scale is set to 100% and "auto-scaling" is turned off prior to printing.