
CCD-18 Card slot x3
A06(joint A05)
Note: external card slot x1
internal card slot x2
Inner card slot cutting orienting line


Silver button
CCD-18 Surface x1
A01
leather rope anchor point


A04 install orienting line
CCD-18 Card slot back leather x1
A05(joint A01)

LZpattern
CCD*18 Long wallet
A3 print 1:1